

Android & Linux

CMUX Driver User Guide

Rev. Android&Linux_CMUX_Driver_User_Guide_V1.0

Date: 2014-05-21



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

Office 501, Building 13, No.99, Tianzhou Road, Shanghai, China, 200233

Tel: +86 21 5108 6236

Mail: info@quectel.com

Or our local office, for more information, please visit:

<http://www.quectel.com/support/salesupport.aspx>

For technical support, to report documentation errors, please visit:

<http://www.quectel.com/support/techsupport.aspx>

GENERAL NOTES

QUECTEL OFFERS THIS INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THIS INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTABLE, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THIS CONTENTS ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2014. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2014-05-21	Joe WANG	Initial

Contents

About the Document.....	2
Contents	3
1 Introduction	4
2 System Integration.....	5
2.1. The Structure of CMUX	5
2.2. Driver Integration.....	5
2.2.1. Get CMUX Driver Source Code	5
2.2.2. Compile Driver	5
2.2.3. Parameters Instruction	6
3 Appendix A Reference.....	7

Quectel
Confidential

1 Introduction

This document mainly introduces how to integrate the CMUX driver into Android or Linux OS for Quectel wireless module.

Quectel
Confidential

2 System Integration

This chapter describes the structure of Android and Linux CMUX driver and explains how to integrate the CMUX driver into Android or Linux OS for Quectel wireless module.

2.1. The Structure of CMUX

The multiplexer provides several virtual connections between TE and MS. TE and MS communicate with each other through the virtual channel. And each channel between TE and MS is called Data Link Connection (DLC) and established separately and sequentially. Each DLC may have individual flow control procedures for buffer management and the aggregate link also has overall flow control mechanisms.




Figure 1: CMUX Structure

2.2. Driver Integration

2.2.1. Get CMUX Driver Source Code

Quectel provides the CMUX source code, please contact Quectel technical support to get it.

2.2.2. Compile Driver

CMUX driver only has one file named "gsm0710muxd_bp.c", you can use the following command to

compile CMUX driver:

```
"gcc -o gsm0710muxd_bp gsm0710muxd_bp.c -lpthread"
```

For embedded system, you should use cross compiler to compile.

2.2.3. Parameters Instruction

1. Here are all parameters for CMUX driver:

- -d: Fork, get a daemon [yes]
- -v: Set verbose logging level. 0 (Silent) - 7 (Debug) [6]
- -s: <serial port name>: Serial port device to connect to [/dev/ttyS0]
- -c: <hardware flow control>: Hardware flow control [disabled]
- -t: <timeout>: Reset modem after this number of seconds of silence [0]
- -P: <pin-code>: PIN code to unlock SIM [-1]
- -p: <number>: Use ping and reset modem after this number of unanswered pings [0]
- -b: <baudrate>: Mode baudrate [115200]
- -m: <modem>: Mode (basic, advanced) [basic]
- -f: <framesize>: Frame size [130]
- -n: <number of ports>: Number of virtual ports to create, must be in the range of 1-31 [3]
- -o: <output log to file>: Output log to /tmp/gsm0710muxd.log [no]
- -h: Show this help message and show current settings.

Parameters in "[]" are the default values.

2. Here are several parameters which are used frequently:

- -s: <serial port name>: Serial port device to connect [/dev/ttyS0]
- -n: <number of ports>: Number of virtual ports to create, must be in the range of 1-31 [3]
- -b: <baudrate>: Mode baudrate [115200]

3. Example of how to run CMUX driver:

```
gsm0710muxd_bp -s /dev/ttyS0 -b 115200 -n 3
```

When CMUX driver is working, it will create several pts files in /dev/pts, and also create several links in /dev/chn. It is better to use links than pts files, because links are always named from 1 to N (N is the parameter you set), while pts files maybe not.

4. Debug

```
-v: Set verbose logging level. 0 (Silent) - 7 (Debug) [6]
```

If debug is needed, set parameter "-v" value to 7 to print all debug message.

3 Appendix A Reference

Table 1: Terms and Abbreviations

Abbreviation	Description
DLC	Data Link Connection
OS	Operating System
TE	Terminal Equipment
MS	Mobile Station